HOW-TO: AUTOMATED EXTERNAL DEFIBRILLATOR

ProfessionalCPR

1 TURN AED ON

Immediately when the AED is received, press the power button and follow the instructions given by the voice prompt.

2 PLACE PADS

Apply the defibrillator pads once prompted to the right upper chest and lower left side of the victim.

Ensure that the chest is dry and removed of any excess hair that might prevent the pads from sticking.

3 PRESS SHOCK BUTTON

Ensure no one is touching the patient before shocking.

Administer a shock if instructed.

Continue to follow all voice prompts.

FOR PURCHASING INQUIRIES, EMAIL US AT INFO@PROCPRCLASSES.COM

(916) 259-0043 www.ProCPRClasses.com